

# COMMANDS MANUAL

HERMES / NEMOS COMMANDS MANUAL



REV 25.01

## Warning

1. This system has been designed to be installed by professionals, not by end users. Please contact our experts for any technical queries you may have.
2. We are continually committed to innovation both in terms of software and hardware. However, errors may result in discrepancies between the product and some of its specifications despite our best efforts to properly document our products. Therefore, please contact us at the following email address should you have any questions or comments: [microcom@microcom.es](mailto:microcom@microcom.es).
3. GSM-based communications are highly reliable. However, we advise against using our device in critical systems unless some form of redundancy has been implemented for the communication network as the service may be interrupted in rare cases.
4. "Life Support": This unit is not designed for use in systems on which human life depends. In other words, in devices where a malfunction could pose a risk to human life.
5. Our liability in relation to the device shall be strictly limited to its repair or replacement in accordance with the terms set forth in the warranty.

All rights reserved. No part of this documentation may be reproduced, stored in a retrieval system, or transmitted by any means (electronic, mechanical, photocopying, recording, or otherwise) without Microcom Sistemas Modulares, S.L.'s prior written consent.

Despite every precaution taken during the preparation of this documentation, neither the publisher nor the author assumes any liability for errors or omissions, or for any damages resulting from the use of the information contained in this document. The information contained in this document is subject to change without notice and does not represent any commitment by Microcom Sistemas Modulares, S.L.

The software described in this document is provided under a non-disclosure agreement. This software may be used or copied in accordance with the terms of these agreements.

© 2003-2025 Microcom Sistemas Modulares, S.L. All rights reserved.

Microcom Sistemas Modulares, S.L.  
C/Gorostiaga, 53 • Irún  
GIPUZKOA • 20305  
Phone number: +34 943 639 724 • Fax +34 943 017 800  
[microcom@microcom.es](mailto:microcom@microcom.es)  
<https://www.microcom360.com>

---

CONTENTS

---

|   |    |
|---|----|
| DOCUMENT CONTENT .....                                    | 4  |
| INFORMATION TABLES .....                                  | 4  |
| 1 - INTRODUCTION .....                                    | 5  |
| 2 - GENERAL ITEMS .....                                   | 5  |
| 2.1    Sending commands via SMS message .....             | 6  |
| 2.2    Sending commands from ZEUSWEB and ZEUSMOBILE ..... | 6  |
| 2.3    Sending command from MICROCONF .....               | 7  |
| 3 - QUERY COMMANDS (VIA SMS) .....                        | 8  |
| 4 - OUTPUT ACTIVATION COMMANDS .....                      | 12 |
| 5 - MODBUS COMMANDS .....                                 | 16 |
| 6 - CONFIGURATION COMMANDS .....                          | 19 |
| 7 - SYSTEM COMMANDS .....                                 | 23 |
| 8 - MICROPLC-II COMMANDS .....                            | 24 |
| 9 - COMMANDS FOR SENDING SMS MESSAGES .....               | 25 |
| 10 - APPENDIX A: LIST OF CHANNEL IDENTIFIERS .....        | 26 |

## DOCUMENT CONTENT

This manual describes the user manuals available for interacting with the Microcom Hermes and Nemos devices.

Other documents of interest include the MicroConf configuration software manual, used for configuring and diagnosing the Microcom Hermes and Nemos series of devices., as well as the MicroPLC-II manual, which details the automation capabilities of the Hermes line. These manuals can be found in the downloads section of the Microcom website.



A set of video tutorials on device configuration and other videos of interest are available on our YouTube channel.



## VERSIONS AND COMPATIBILITY

The information shown in this document corresponds to the version of the MicroConf configuration software and firmware of the Hermes / Nemos indicated below:

| Element            | Version |
|--------------------|---------|
| MicroConf Software | v.9.3.4 |
| Firmware           | v.9.40  |

## INFORMATION TABLES

The following information tables are used throughout the manual:



**Please note:** These are used to highlight information of special importance or interest.



**Please note:** These are used to describe the conditions, practices or procedures that must be followed for the proper use of hardware or software.



**Example:** These are used to show practical examples and therefore help to better understand the text described in the section.

## 1 - INTRODUCTION

Microcom devices accept a wide variety of commands that allow users to interact with them. Users can use these commands to query the device about the status of its inputs/outputs, modify the status of the outputs, change MODBUS register values, modify configuration parameters, and change system settings.

Commands can be sent by SMS message, the ZEUSWEB platform, the ZEUSMOBILE mobile app, and the MICROCONF configuration software.



- Please note that Microcom devices only respond to SMS messages from phones on their authorised phone number list.
- Unless otherwise specified, updating your device to the latest available firmware version is required to ensure compatibility with the commands described in this document.

We recommend that you read this manual carefully to fully make use of the capabilities of your Hermes/Nemos device.

## 2 - GENERAL ITEMS

Commands consist of a keyword and optionally an equals sign followed by a list of modifiers separated by commas:

Keyword=Equality Operator,modifier1,modifier2,...,modifier n



**Command example:** In this example, the keyword is +TLF, where adding an authorised phone number to the list; the equality operator is +34637885326, while the rest are modifiers.

```
+TLF=+34637885326,PRIO=1,PRV2
```



Microcom devices are not case-sensitive when it comes to commands.

Commands can be chained, meaning that several commands can be sent consecutively, which must be separated by a semicolon. Uppercase and lowercase letters can be used interchangeably in all commands. Via SMS, the maximum length is defined by the maximum number of characters allowed, which is 160.



**Chained command example:** In this example, three commands are chained to activate digital outputs 1, 2, and 3.

```
OUT1=1;OUT2=1;OUT3=1
```

## 2.1 SENDING COMMANDS VIA SMS MESSAGE

Sending commands from a mobile phone. Each valid command received by the Hermes/Nemos device is acknowledged by sending a reply message to the sender. An error message will be sent if the command is invalid.

| Command  | Response  |
|--|---|
| Sending of the valid command<br><br><b>INFO?</b> | VBat=11.66<br>Temperature: 20.90C<br>Moisture: 51.11R.H.<br>Network failure: No<br>-<br>Device: Microcom<br>03/05/2024 10:31:09 |
| Sending of an invalid command<br><br><b>INFO</b> | Invalid command<br>-<br>Device: Microcom  |


## 2.2 SENDING COMMANDS FROM ZEUSWEB AND ZEUSMOBILE

Sending commands via web browser and mobile app. This method allows commands to be sent to multiple stations simultaneously, without having to pay the cost of sending SMS messaging. The Hermes/Nemos device must be registered with the ZEUS server and actively transmitting data.

Instructions:

1. Access your ZEUS account through the website or on a mobile app.
2. Go to the "Administration / Settings" screen.
3. Click on the "Send Commands" tab.
4. Select the Hermes/Nemos station(s).
5. Enter the command and click the send button.

The status of the command transmission is displayed in the right-hand column.


| Response  | Description  |
|---|--|
| X   | Error when sending the command. Check GSM connectivity in the Hermes/Nemos station         |
| V   | Error: the command received could not be executed. Please check the keyword and modifiers. |
|  | Command being sent   |

### 2.3 SENDING COMMAND FROM MICROCONF

Sending command from configuration software. The Hermes/Nemos device must be connected to the computer with a USB cable or via Bluetooth.

Instructions:

1. Go to the "Terminal" screen. [Menu] > [Diagnostics] > [Terminal]
2. Type the command in the field to the right of the [Send Command] button.
3. Press the [Send Command] button.



The Hermes/Nemos response will be displayed in the upper panel.

| Response        | Description  |
|-----------------|--|
| #74;PARSE_OK    | Command executed successfully.   |
| #64;PARSE_ERROR | Error: the command received could not be executed. Please check the keyword and modifiers. |




### 3- QUERY COMMANDS (VIA SMS)




Below is a list of query commands that will allow you to read the status of the device's inputs/outputs, as well as its operational parameters.







This list of commands is only compatible with SMS communication.

| Command                         | Description   |
|---------------------------------|---|
| <p><b>INFO?</b></p>             | <p>Information request. The device responds with the status of the channels configured to record data: digital inputs, flow rates, analogue inputs, probes, math channels, MODBUS channels, etc.</p> <div style="border: 1px solid #ccc; padding: 5px; margin-top: 10px;"> <p><i>Example:</i> Response SMS:</p> <p>Temperature: 20.90C      (Analogue input value)</p> <p>Moisture: 51.11R.H.      (Analogue input value)</p> <p>Network failure: No      (Digital input status)</p> <p>-</p> <p>Microcom                      (Device name)</p> </div> |
| <p><i>INFO=Phone Number</i></p> | <p>This command triggers the sending of an "INFO?" message to the specified phone number. The main purpose of this command is to create a macro that can be scheduled from a timer, allowing the device to send an informational SMS message to the specified phone number on a periodic basis.</p> <div style="border: 1px solid #ccc; padding: 5px; margin-top: 10px;"> <p><i>Example:</i> INFO=+34637885326</p> </div>   |




| Command                                       | Description   |
|---|---|
| <p>INFOC=ChannelList<br/>DEST=PhoneNumber</p> | <p>This command queries the device for the status of the channels specified in the <i>ChannelList</i>. The main purpose of this command is to create a user macro that returns the status of the relevant input/output channels in the system.</p> <p> The DEST parameter is optional and allows you to specify the phone number to which the message should be sent.</p> <p> <a href="#">Appendix A</a> contains the list of channel identifiers. The ChannelList parameter will consist of a variable number of these identifiers, separated by spaces.</p> <p> To request data from channels 4 (totaliser 0), 21 (digital input 0) and 29 (MODBUS channel 0):<br/>INFOC=4 21 29</p> <p> To request data from channels 4 (totaliser 0), 21 (digital input 0) and 29 (MODBUS channel 0) and to have it sent to a phone number:<br/>INFOC=4 21 29,DEST=+34666555444</p> |
| <p>GSM?</p>                                   | <p>Query regarding GSM signal strength and mobile data communication status.</p> <p> <b>Example:</b> Response SMS:<br/>Movistar (2G) (Operator and network)<br/>RSSI=24 (*RSSI signal strength coverage)<br/>GPRS=Yes (Access to internet data)<br/>-<br/>Microcom (Device name)</p> <p> <b>RSSI:</b> The device returns a numeric value between 1 and 32. The recommended minimum is 8. Conversion equation to dBm:<br/><math display="block">\text{dBm} = -113 + N * 2</math> (where N is the returned value)</p>   |
| <p>LAN?</p>                                   | <p>Returns the IP address for both Ethernet and Wi-Fi connections. If no connection is available, the response will be 0.0.0.0.</p> <p> <b>Example:</b> Response SMS:<br/>Ethernet: 192.168.1.151 (IP Ethernet)<br/>Wifi: 0.0.0.0 (IP Wifi)<br/>-<br/>Microcom M103 pump (Device name)</p>   |



| Command                  | Description   |              |                    |                          |                             |          |                            |              |                    |                   |                 |       |                               |            |                  |         |                       |                  |                           |             |                      |   |  |          |               |
|--------------------------|---|--------------|--------------------|--------------------------|-----------------------------|----------|----------------------------|--------------|--------------------|-------------------|-----------------|-------|-------------------------------|------------|------------------|---------|-----------------------|------------------|---------------------------|-------------|----------------------|---|--|----------|---------------|
| CNT?                     | Request for status of all totaliser counters. The device responds with an SMS message indicating the value of the totaliser counters for each of its digital inputs.  |              |                    |                          |                             |          |                            |              |                    |                   |                 |       |                               |            |                  |         |                       |                  |                           |             |                      |   |  |          |               |
| CNTx?                    | <p>Request for the status of a specific totaliser counter. The device responds with an SMS message indicating the value of the counter connected to the digital input in the parameter [x].</p> <div style="display: flex; align-items: center;">  <div style="border-left: 1px solid #ccc; padding-left: 10px;"> <p><b>Example:</b> Request for the total status of digital input 1: CNT1?</p> </div> </div>  |              |                    |                          |                             |          |                            |              |                    |                   |                 |       |                               |            |                  |         |                       |                  |                           |             |                      |   |  |          |               |
| OUT?                     | Returns the status of all the device outputs.   |              |                    |                          |                             |          |                            |              |                    |                   |                 |       |                               |            |                  |         |                       |                  |                           |             |                      |   |  |          |               |
| EXPx?                    | <p>Returns the value of expansion channel x.</p> <div style="display: flex; align-items: center;">  <div style="border-left: 1px solid #ccc; padding-left: 10px;"> <p>This command is only available for devices from the Hermes M100 series.</p> </div> </div> <div style="display: flex; align-items: center; margin-top: 10px;">  <div style="border-left: 1px solid #ccc; padding-left: 10px;"> <p><b>Example:</b><br/>EXP50?</p> </div> </div>   |              |                    |                          |                             |          |                            |              |                    |                   |                 |       |                               |            |                  |         |                       |                  |                           |             |                      |   |  |          |               |
| DEVICE?                  | <p>Returns the device's technical parameters.</p> <div style="border-left: 1px solid #ccc; padding-left: 10px; margin-top: 10px;"> <p><b>Response SMS example</b> (can take up 2 SMS):</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">VERSION=9.22</td> <td>(Firmware version)</td> </tr> <tr> <td>DATE=Feb 5 2024 13:41:39</td> <td>(Firmware compilation date)</td> </tr> <tr> <td>CRC=Good</td> <td>(Firmware integrity check)</td> </tr> <tr> <td>PRODUCT_ID=6</td> <td>(Model identifier)</td> </tr> <tr> <td>SERIAL=2208010010</td> <td>(Serial number)</td> </tr> <tr> <td>PIC=0</td> <td>(Secondary processor version)</td> </tr> <tr> <td>VBAT=11.66</td> <td>(Supply voltage)</td> </tr> <tr> <td>RSSI=24</td> <td>(GSM signal strength)</td> </tr> <tr> <td>LOG.INDEX=550400</td> <td>(History register number)</td> </tr> <tr> <td>CONF_WORD=0</td> <td>(Configuration word)</td> </tr> <tr> <td>-</td> <td></td> </tr> <tr> <td>Microcom</td> <td>(Device name)</td> </tr> </table> </div> | VERSION=9.22 | (Firmware version) | DATE=Feb 5 2024 13:41:39 | (Firmware compilation date) | CRC=Good | (Firmware integrity check) | PRODUCT_ID=6 | (Model identifier) | SERIAL=2208010010 | (Serial number) | PIC=0 | (Secondary processor version) | VBAT=11.66 | (Supply voltage) | RSSI=24 | (GSM signal strength) | LOG.INDEX=550400 | (History register number) | CONF_WORD=0 | (Configuration word) | - |  | Microcom | (Device name) |
| VERSION=9.22             | (Firmware version)  |              |                    |                          |                             |          |                            |              |                    |                   |                 |       |                               |            |                  |         |                       |                  |                           |             |                      |   |  |          |               |
| DATE=Feb 5 2024 13:41:39 | (Firmware compilation date)   |              |                    |                          |                             |          |                            |              |                    |                   |                 |       |                               |            |                  |         |                       |                  |                           |             |                      |   |  |          |               |
| CRC=Good                 | (Firmware integrity check)  |              |                    |                          |                             |          |                            |              |                    |                   |                 |       |                               |            |                  |         |                       |                  |                           |             |                      |   |  |          |               |
| PRODUCT_ID=6             | (Model identifier)  |              |                    |                          |                             |          |                            |              |                    |                   |                 |       |                               |            |                  |         |                       |                  |                           |             |                      |   |  |          |               |
| SERIAL=2208010010        | (Serial number)   |              |                    |                          |                             |          |                            |              |                    |                   |                 |       |                               |            |                  |         |                       |                  |                           |             |                      |   |  |          |               |
| PIC=0                    | (Secondary processor version)   |              |                    |                          |                             |          |                            |              |                    |                   |                 |       |                               |            |                  |         |                       |                  |                           |             |                      |   |  |          |               |
| VBAT=11.66               | (Supply voltage)  |              |                    |                          |                             |          |                            |              |                    |                   |                 |       |                               |            |                  |         |                       |                  |                           |             |                      |   |  |          |               |
| RSSI=24                  | (GSM signal strength)   |              |                    |                          |                             |          |                            |              |                    |                   |                 |       |                               |            |                  |         |                       |                  |                           |             |                      |   |  |          |               |
| LOG.INDEX=550400         | (History register number)   |              |                    |                          |                             |          |                            |              |                    |                   |                 |       |                               |            |                  |         |                       |                  |                           |             |                      |   |  |          |               |
| CONF_WORD=0              | (Configuration word)  |              |                    |                          |                             |          |                            |              |                    |                   |                 |       |                               |            |                  |         |                       |                  |                           |             |                      |   |  |          |               |
| -                        |   |              |                    |                          |                             |          |                            |              |                    |                   |                 |       |                               |            |                  |         |                       |                  |                           |             |                      |   |  |          |               |
| Microcom                 | (Device name)   |              |                    |                          |                             |          |                            |              |                    |                   |                 |       |                               |            |                  |         |                       |                  |                           |             |                      |   |  |          |               |





| Command  | Description  |
|--|--|
| <p><b>OPER?</b></p>                             | <p>Scans the network and returns the field strength of all detected operators.</p> <p><i>Response SMS example:</i></p> <p>Movistar: 31 (operator 1 RSSI)<br/>           Orange: 24 (operator 2 RSSI)<br/>           Vodafone ES: 22 (operator 3 RSSI)<br/>           -<br/>           Microcom (Device name)</p>   |
| <p><b>VER?</b></p>                              | <p>Returns the device model, firmware version, and the date it was compiled.</p> <p><i>Response SMS example:</i></p> <p>Nemos N200+ v8.81 Feb 17 2022 11:06:28<br/>           -<br/>           Test (Device name)</p>  |
| <p><b>MODBUS?</b></p>                         | <p>Returns the values of the configured MODBUS channels.</p> <p><i>Response SMS example:</i></p> <p>TEMP_MB: 24.40C (Name, measurement and unit)<br/>           HUM_MB: 53.60% (Name, measurement and unit)<br/>           -<br/>           Microcom (Device name)</p>   |
| <p><b>MODBUS=</b><br/><i>PhoneNumber</i></p>  | <p>This command sends the MODBUS channel values to the specified phone number. The main purpose of this command is to create a macro that can be scheduled from a timer, allowing the device to send an SMS message on a periodic basis.</p> <p><i>Example:</i> Sending the values of the configured MODBUS channels to the phone number+34666555444.</p> <p>MODBUS=+34666555444</p> <p><i>Response SMS example:</i></p> <p>TEMP_MB: 24.40C (Name, measurement and unit)<br/>           HUM_MB: 53.60% (Name, measurement and unit)<br/>           -<br/>           Microcom (Device name)</p> |



## 4 - OUTPUT ACTIVATION COMMANDS

The following list shows the commands that allow you to control the device's output.

| Command   | Description  |
|---|--|
|   | Modifies the status of a digital output.   |
| <p><i>OUT</i><i>x</i>=<i>y</i>,<br/><i>T</i>=<i>timeSeconds</i>,<br/><i>TM</i>=<i>timeMinutes</i></p> | <p> <b>Where:</b><br/> <i>x</i>: Output to be modified.<br/> <i>y</i>: State the output should be in: 0 -&gt; disabled, 1 -&gt; enabled.<br/> <i>timeSeconds</i>: Time in seconds. After this period has elapsed, the output will return to its previous state.<br/> <i>timeMinutes</i>: Time in minutes. After this period has elapsed, the output will return to its previous state</p> |
|   | <p> The property for setting the start time in minutes is valid from firmware version 8.82 onwards.</p>   |
|   | <p><b>Examples:</b><br/> Close relay 0: <i>OUT</i>0=1<br/> Generates a 10-second pulse in relay 0: <i>OUT</i>0=1,<i>T</i>=10<br/> Generates a 2-minute pulse in relay 0: <i>OUT</i>0=1,<i>TM</i>=2</p>   |
|   | <p> Starting with firmware version 8.45, this command supports comparison expressions for “<i>y</i>”.</p>   |
|   | <p><b>Example:</b><br/> Activates output 0 if the value of analogue input 0 is greater than a constant. Otherwise, the output will remain open.<br/> <i>OUT</i>0=<i>AI</i>(0)&gt;3.5</p>   |









| Command   | Description  |                              |                |               |      |   |           |   |   |           |   |   |           |   |   |           |   |   |           |   |    |           |   |    |           |   |    |           |   |     |           |
|---|--|------------------------------|----------------|---------------|------|---|-----------|---|---|-----------|---|---|-----------|---|---|-----------|---|---|-----------|---|----|-----------|---|----|-----------|---|----|-----------|---|-----|-----------|
|                | <p>Command valid from firmware version 8.82 onwards.</p>   |                              |                |               |      |   |           |   |   |           |   |   |           |   |   |           |   |   |           |   |    |           |   |    |           |   |    |           |   |     |           |
| <p>OUTP=y</p>  | <p>Digital output port status modification.</p> <p><i>Where:</i></p> <p>y: This represents the status of the output port in decimal format. In binary representation, the least significant bit corresponds to output OUT0, while the most significant bit corresponds to OUT7. This command allows the status of multiple outputs to be modified simultaneously by adding their decimal values.</p> <table border="1" data-bbox="687 801 1509 1252"> <thead> <tr> <th><i>Digital output active</i></th> <th><i>Decimal</i></th> <th><i>Binary</i></th> </tr> </thead> <tbody> <tr> <td>none</td> <td>0</td> <td>0000 0000</td> </tr> <tr> <td>0</td> <td>1</td> <td>0000 0001</td> </tr> <tr> <td>1</td> <td>2</td> <td>0000 0010</td> </tr> <tr> <td>2</td> <td>4</td> <td>0000 0100</td> </tr> <tr> <td>3</td> <td>8</td> <td>0000 1000</td> </tr> <tr> <td>4</td> <td>16</td> <td>0001 0000</td> </tr> <tr> <td>5</td> <td>32</td> <td>0010 0000</td> </tr> <tr> <td>6</td> <td>64</td> <td>0100 0000</td> </tr> <tr> <td>7</td> <td>128</td> <td>1000 0000</td> </tr> </tbody> </table> <p><i>Example:</i></p> <p>To activate digital outputs 1 (2 decimal) and 2 (4 decimal).<br/>Binary representation: 0000 0110 OUTP=6</p> <p>To deactivate all the digital outputs: OUTP=0</p> | <i>Digital output active</i> | <i>Decimal</i> | <i>Binary</i> | none | 0 | 0000 0000 | 0 | 1 | 0000 0001 | 1 | 2 | 0000 0010 | 2 | 4 | 0000 0100 | 3 | 8 | 0000 1000 | 4 | 16 | 0001 0000 | 5 | 32 | 0010 0000 | 6 | 64 | 0100 0000 | 7 | 128 | 1000 0000 |
| <i>Digital output active</i>  | <i>Decimal</i>   | <i>Binary</i>                |                |               |      |   |           |   |   |           |   |   |           |   |   |           |   |   |           |   |    |           |   |    |           |   |    |           |   |     |           |
| none  | 0  | 0000 0000                    |                |               |      |   |           |   |   |           |   |   |           |   |   |           |   |   |           |   |    |           |   |    |           |   |    |           |   |     |           |
| 0   | 1  | 0000 0001                    |                |               |      |   |           |   |   |           |   |   |           |   |   |           |   |   |           |   |    |           |   |    |           |   |    |           |   |     |           |
| 1   | 2  | 0000 0010                    |                |               |      |   |           |   |   |           |   |   |           |   |   |           |   |   |           |   |    |           |   |    |           |   |    |           |   |     |           |
| 2   | 4  | 0000 0100                    |                |               |      |   |           |   |   |           |   |   |           |   |   |           |   |   |           |   |    |           |   |    |           |   |    |           |   |     |           |
| 3   | 8  | 0000 1000                    |                |               |      |   |           |   |   |           |   |   |           |   |   |           |   |   |           |   |    |           |   |    |           |   |    |           |   |     |           |
| 4   | 16   | 0001 0000                    |                |               |      |   |           |   |   |           |   |   |           |   |   |           |   |   |           |   |    |           |   |    |           |   |    |           |   |     |           |
| 5   | 32   | 0010 0000                    |                |               |      |   |           |   |   |           |   |   |           |   |   |           |   |   |           |   |    |           |   |    |           |   |    |           |   |     |           |
| 6   | 64   | 0100 0000                    |                |               |      |   |           |   |   |           |   |   |           |   |   |           |   |   |           |   |    |           |   |    |           |   |    |           |   |     |           |
| 7   | 128  | 1000 0000                    |                |               |      |   |           |   |   |           |   |   |           |   |   |           |   |   |           |   |    |           |   |    |           |   |    |           |   |     |           |

| Command  | Description  |
|--|--|
|  | <p>Modifies the status of a digital or analogue output in an expansion channel or changes the value of a totaliser configured on an expansion channel.</p>   |
|  | <p> This command is only valid for the Hermes M100 series.</p>  |
| <p>EXPx=y,<br/>T=timeSeconds,<br/>TM=timeMinutes</p> | <p> <b>Where:</b><br/> <i>x</i>: Expansion channel assigned to the digital output you wish to activate.<br/> <i>y</i>: The value to be set in the totaliser, the value of an analogue output, or the status that a digital output should have.<br/>           0 -&gt; output deactivated<br/>           1 -&gt; output activated.<br/> <i>timeSeconds</i>: Time in seconds. After this period has elapsed, the output will return to its previous state<br/> <i>timeMinutes</i>: Time in minutes. After this period has elapsed, the output will return to its previous state</p> |
|  | <p> The property for setting the start time in minutes is valid from firmware version 9.40 onwards.</p>   |
|  | <p> <b>Examples:</b></p> <ul style="list-style-type: none"> <li>- To activate the digital output of expansion module 2:<br/>EXP2=1</li> <li>- To send a value to the expansion 16 analogue output.<br/>EXP16=35</li> <li>- To set the value 123.45 on a totaliser configured in expansion 16:<br/>EXP16=123.45</li> <li>- Activates the expansion 2 output for 30 seconds:<br/>EXP2=1,T=30</li> <li>- Generates a 2- minute pulse in relay 0:<br/>OUT0=1,TM=2</li> </ul>  |

| Command                    | Description   |
|----------------------------|---|
| <p>CNT<math>x=y</math></p> | <p>Modifies the value of a totaliser configured on a digital input.</p> <div style="border-left: 1px solid #ccc; border-right: 1px solid #ccc; padding: 5px;"> <p> <b>Where:</b><br/> <math>x</math>: Expansion channel assigned to the digital output you wish to activate.<br/> <math>y</math>: Value to be configured in the totaliser.</p> <hr/> <p> <b>Example:</b><br/>           To set the value 123.45 in the totaliser associated with digital input 4:<br/>           CNT4=123.45</p> </div> |

## 5 - MODBUS COMMANDS

The following list shows the commands related to the MODBUS interface.

| Command   | Description   |
|---|---|
|   | Activates a bit (COIL) of a MODBUS device   |
| SETCOIL= <i>Relay</i><br>SLAVE= <i>Address</i><br>SERVER= <i>server</i>   |  <p><b>Where:</b><br/> <i>Relay:</i> Relay to activate on the output module.<br/> <i>Address:</i> MODBUS address for the output module in decimals.<br/> <i>Server:</i> Server name (only TCP)</p>   |
|   |  <p><b>Examples:</b><br/>           Activates output 0 in the module with address 20 indefinitely:<br/>           SETCOIL=0,SLAVE=20</p>   |
|   |  <p>MODBUS-TCP is supported from firmware version 9.37 onwards.</p>  |
|   |  <p><b>TCP examples:</b><br/>           Activates output 0 of the server "VARIA" indefinitely:<br/>           SETCOIL=0,SERVER=VARIA</p>   |
|   | The opposite of SETCOIL, where a bit is deactivated in a MODBUS device.   |
| RESETCOIL= <i>Relay</i><br>SLAVE= <i>Address</i><br>SERVER= <i>server</i> |  <p><b>Where:</b><br/> <i>Relay:</i> Relay to activate on the output module.<br/> <i>Address:</i> MODBUS address for the output module in decimals.<br/> <i>Server:</i> Server name (only TCP)</p> |
|   |  <p><b>Examples:</b><br/>           Deactivates output 0 in the module with address 20 indefinitely:<br/>           RESETCOIL=0,SLAVE=20</p>   |
|   |  <p>MODBUS-TCP is supported from firmware version 9.37 onwards.</p>  |
|   |  <p><b>TCP examples:</b><br/>           Activates output 0 of the server "VARIA" indefinitely:<br/>           RESETCOIL=0,SERVER=VARIA</p>   |

Writes in a MODBUS register.



**Where:**

*Value:* Value or signal to be loaded into the register.

*Address:* MODBUS slave address

*Server:* Server name (only TCP)

*Register:* Register address to be written.

*Type:* Selects the 32-bit value format (optional):

- I32BE: Sending of a 32-bit value as an integer and big endian.
- I32LE: Sending of a 32-bit value as an integer and little endian.
- F32BE: Sending of a 32-bit value as a float and big endian.
- F32LE: Sending of a 32-bit value as a float and little endian.



The value can be a complex expression from firmware version 7.47 onwards.



**RTU examples:**

Loads the value 100 to the address 40001 of slave 3:

SETREGISTER=100,SLAVE=3,REGADD=40001

Writes the value of analogue input 0:

SETREGISTER=AI(0),SLAVE=3,REGADD=40001

Writes the value of the math register 0 plus one:

SETREGISTER=M(0)+1,SLAVE=3,REGADD=40001



32-bit values can be written from firmware version 8.01 onwards.



**Examples 32 bits:**

Writes the value 100 in the address 40001 of slave 3, integer data type and big-endian:

SETREGISTER=100,SLAVE=3,REGADD=40001,I32BE

Writes the value of the analogue input 0, float and big endian type.

SETREGISTER=AI(0),SLAVE=3,REGADD=40001,F32BE



MODBUS-TCP is supported from firmware version 9.14 onwards.



**TCP examples:**


Writes the value 100 in the 40001 of the "VARIA" server.

SETREGISTER=10,SERVER=VARIA,REGADD=40001

Writes the value of the analogue input 0, float and big endian type:

SETREGISTER=AI0,SERVER=VARIA,REGADD=40001,F32BE

SETREGISTER= *Value*  
SLAVE= *Address*  
SERVER= *server*  
REGADD= *Register, type*

| Command                       | Description  |
|-------------------------------|--|
| <p>MODBUSTX= <i>Frame</i></p> | <p>Triggers the sending of the specified frame via the MODBUS channel.</p> <div style="border: 1px solid #ccc; padding: 10px;"> <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 10px; text-align: center;">  </div> <div> <p><b>Where:</b></p> <p><i>Frame:</i> This is the string to be sent via the MODBUS port in hexadecimal encoded ASCII.</p> <hr/> <p><b>Example:</b></p> <p>Activates a relay output on a device with address 01. The frame format is:</p> <p>ADDRESS   FUNCTION   COIL_ADDRES   DATA   CRC</p> <p>In this case, ADDRESS is 01, FUNCTION is 05 (Force single coil), COIL_ADDRESS is 0001, and DATA is FF00 (to close the relay). <b>The CRC field should not be added, as it is calculated by the device itself.</b></p> <p>The command to force the transmission of this command is:</p> <p>MODBUSTX=01050001FF00</p> </div> </div> </div> |

## 6 - CONFIGURATION COMMANDS

The following shows the configuration command list.


















**Please note:** Send the command with an empty equals sign to delete a parameter.







**Example:**  
Manually delete password APN:  
APNPASS=

| Command                    | Description   |
|----------------------------|---|
| <i>ID=Name</i>             | <p>Sets the device name.</p> <p><b>Example:</b><br/>ID=Microcom</p>   |
| <i>LATITUDE=latitude</i>   | <p>Geographic coordinates settings. Sets the latitude in decimal degrees format.</p> <p><b>Example:</b><br/>LATITUDE=43.33648</p>   |
| <i>LONGITUDE=longitude</i> | <p>Geographic coordinates settings. Sets the longitude in decimal degrees format.</p> <p><b>Example:</b><br/>LONGITUDE=-1.81351</p> |
| <i>CSM=CentreSMS</i>       | <p>Configures the short message service centre.</p> <p><b>Example:</b><br/>CSM=+34609090909</p>                                     |
| <i>PTLF=TfnNumber</i>      | <p>Sets the number itself.</p> <p><b>Example:</b><br/>PTLF=+34637885326</p>   |
| <i>GPRSEN</i>              | <p>Enable mobile data usage.</p>  |



| Command                                   | Description   |
|---|---|
| <b>GPRSDIS</b>                            | Disables mobile data usage.   |
| <b>APNSERVER=</b><br><i>APNserver</i>     | <p>Sets the APN server for GPRS connections.</p> <p> <b>Example:</b><br/>APNSERVER=movistar.es</p>   |
| <b>APNUSER=</b><br><i>APNuser</i>         | <p>Sets the APN server user for GPRS connections.</p> <p> <b>Example:</b><br/>APNUSER=movistar</p>   |
| <b>APNPASS=</b><br><i>APNpassword</i>     | <p>Sets the APN server password for GPRS connections.</p> <p> <b>Example:</b><br/>APNPASS=movistar</p>  |
| <b>APNALCON=0/1</b>                       | <p>Enables or disables the permanent connection.</p> <p> <b>Examples:</b><br/>Enables the permanent connection. APNALCON=1<br/>Disables the permanent connection: APNALCON=0</p>   |
| <b>SERVERIP=</b><br><i>AddressIP, TSL</i> | <p>Sets the IP address for the Zeus server. The IP format is XXX.XXX.XXX.XXX.</p> <p> The URL can be used from the firmware version 7.47 onwards.</p> <p> <b>TSL:</b> Is optional. TLS protocol is enabled when this modifier is sent.</p> <p> <b>Example:</b><br/>SERVERIP= 082.223.197.145<br/>SERVERIP= zeus.microcom.es<br/>SERVERIP= zeus.microcom.es,TSL</p> |

| Command  | Description  |
|--|--|
| SERVERPORT=Port  | <p>Sets the port for the Zeus server.</p> <p> <b>Example:</b><br/>SERVERPORT=8080</p>   |
| FTPIP=<br><i>FtpDireccionIP, TSL</i>                     | <p>Sets the IP address for the FTP server. The IP format is XXX.XXX.XXX.XXX. The default port is 21.</p> <p> The TLS protocol can be used from the firmware version 9.03 onwards.</p> <p> <b>TSL:</b> Is optional. TLS protocol is enabled when this modifier is sent.</p> <p> <b>Examples:</b><br/>FTPIP= 082.223.197.145<br/>FTPIP=082.223.197.145,TSL</p> |
| FTPUSER= <i>FtpUser</i>                                  | <p>Sets the user for the FTP server.</p> <p> <b>Example:</b><br/>FTPUSER =seh915678</p>   |
| FTPPASS=<br><i>FtpPassword</i>                           | <p>Sets the password for the FTP server.</p> <p> <b>Example:</b><br/>FTPPASS =TestFTP</p>   |
| FTPPATH= <i>FtpPath</i>                                  | <p>Sets the path for the FTP server.</p> <p> <b>Example:</b><br/>FTPPATH =/data/test</p>  |
| +TLF= <i>Phonenumber,</i><br>PRIO= <i>Prioriity,PRVx</i> | <p>Adds a phone number to the authorised list. The international country code with the phone number should be stated (Spain +34).</p> <p> <b>Where:</b><br/><i>Phone number:</i> Phone number to be added in international format, unless it is a corporate number.<br/><i>Priority:</i> Number priority. 0 no priority, 1 highest priority, 8</p>  |

| Command                             | Description  |
|-------------------------------------|--|
|                                     | lowest priority.<br><i>PRV</i> x: Privilege level<br>PRV0 -> User<br>PRV1 -> Advanced user<br>PRV2 -> Administrator  |
|                                     |  <p><b>Example:</b><br/>Add phone number with priority 1 and advanced user privileges<br/>+TLF=+34637885326,PRIO=1,PRV3</p> |
|                                     | Removes a number from the list of authorised numbers.  |
| <i>TLF=Telephonenumber</i>          |  <p><b>Example:</b><br/>-TLF=+34637885326</p>   |
| <b>CLRTL</b>                        | Removes all numbers from the list of authorised numbers.   |
|                                     | Adds a phone number of the “voice authorised” list. The international country code with the phone number should be stated (Spain +34).   |
| <b>+TEL</b>                         |  <p><b>Example:</b><br/>+TEL=+34666555444</p>   |
|                                     | Removes a phone number from the “voice authorised” list.   |
| <b>-TEL</b>                         |  <p><b>Example:</b><br/>-TEL=+34666555444</p>   |
| <b>CLRTEL</b>                       | Removes all phone numbers from the “voice authorised” list.  |
|                                     | Sets the access password for: CSD data calls and local connection options (USB and Bluetooth). The default password is 1234. The password consists of 4 numeric digits.                                      |
| <b>PASSWORD=</b><br><i>password</i> |  <p><b>Example:</b><br/>PASSWORD=1234</p>   |



## 7 - SYSTEM COMMANDS

The following shows the system command list.

| Command    | Description   |
|------------|---|
| TCPCONNECT | Triggers the immediate connection to the Zeus server via GPRS.  |
| FTPCONNECT | Triggers the immediate connection to the FTP server.  |
| UPDATE     | <div style="display: flex; align-items: center;">  <div> <p>Command valid from firmware version 8.82 onwards.</p> <p>Updates the firmware via GPRS. When it receives this command, the device downloads the latest firmware version from the Microcom FTP server and installs it. This process does not modify the device's configuration.</p> </div> </div> |
| LDDEF      | Resets the device to its factory settings. Deletes the device settings and any data stored in memory (historical registers).  |
| LOGCLR     | <div style="display: flex; align-items: center;">  <div> <p>Command valid from firmware version 8.31 onwards.</p> <p>Deletes the data stored in the memory (historical registers).</p> </div> </div>   |
| SNTPSYNC   | This process causes the device to synchronise its internal clock with the time from the internet network. This synchronisation procedure requires the device to be correctly configured to access the internet.   |
| ENPOF      | Enables "sleep mode" or low-power mode on devices from the Nemos series.  |
| DISPOF     | Disables "sleep mode" or low-power mode on devices from the Nemos series.   |
| ALMREC     | Acknowledgement of receipt for alarms configured with forwarding enabled. Sending this command will cause the Microcom device to stop forwarding alarm notifications.   |
| REBOOT     | Triggers a complete system restart.   |






## 8 - MICROPLC-II COMMANDS

The following list shows the commands related to the running of the MicroPLC.

| Command                | Description   |
|------------------------|---|
| PLCRUN                 | Starts up the MicroPLC-II. This command needs to be used if the system is going to STOP due to running a script remotely that contains an error.  |
| PLCSTOP                | Halts the running of the MicroPLC-II. When the system is in STOP mode, inputs are still being registered, but outputs cannot be activated.  |
| PLCEXE= <i>command</i> | <p>Allows MicroPLC-II commands to be run.</p> <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 10px;">  </div> <div> <p><b>Where:</b><br/>Command: Any command available in the MicroPLC-II is valid.</p> </div> </div> <hr style="border: 0.5px solid #00a0e3;"/> <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 10px;">  </div> <div> <p><b>Example:</b><br/>Indicates a value for the analogue output in mA:<br/>PLCEXE=EXP16.MA=6.7</p> </div> </div> |

## 9 - COMMANDS FOR SENDING SMS MESSAGES

The following shows the list of commands that trigger the sending of SMS messages.

| Command   | Description  |
|---|--|
| <p><i>SMS=Message</i><br/><i>DEST=Destination</i></p>     | <p>This feature allows a Microcom device to send an SMS message to a phone number. This is a useful command for retrieving the phone number of the SIM card inserted in the Microcom device.</p> <div style="border: 1px solid #ccc; padding: 5px;"> <p> <b>Where:</b><br/> <i>Message:</i> Message text.<br/> <i>Destination:</i> Phone number in international format.</p> </div> <hr/> <div style="border: 1px solid #ccc; padding: 5px;"> <p> <b>Example:</b><br/>           Sends a message with the text "TEST" to the phone number +34666555444<br/><br/>           SMS=TEST,DEST=+34666555444</p> </div> <hr/> <div style="border: 1px solid #ccc; padding: 5px;"> <p> Command valid from firmware version 8.44 onwards.</p> </div> |
| <p><i>SMSCOM="command</i><br/><i>DEST=Destination</i></p> | <p>This feature enables communication between Microcom devices via SMS. This command does not generate a response from the receptor. This command is useful for sending commands between different Microcom devices.</p> <div style="border: 1px solid #ccc; padding: 5px;"> <p> <b>Where:</b><br/> <i>Message:</i> Command that you wish the remote Hermes/Nemos device to execute. The command must be enclosed in double quotes.<br/> <i>Destination:</i> Remote Hermes/Nemos phone number in international format.</p> </div> <hr/> <div style="border: 1px solid #ccc; padding: 5px;"> <p> <b>Example:</b><br/>           Enter the number 1 into the math register 0 of the device with the phone number.+34666555444<br/><br/>           SMSCOM="M(0)=1",DEST=+34666555444</p> </div>                               |

## 10 - APPENDIX A: LIST OF CHANNEL IDENTIFIERS

| Identifier | Channel                              |
|------------|--------------------------------------|
| 0          | Analogue input 0                     |
| 1          | Analogue input 1                     |
| 2          | Analogue input 2                     |
| 3          | Analogue input 3                     |
| 4          | Digital input 0 totaliser counter    |
| 5          | Digital input 1 totaliser counter    |
| 6          | Digital input 2 totaliser counter    |
| 7          | Digital input 3 totaliser counter    |
| 8          | Digital input 4 totaliser counter    |
| 9          | Digital input 5 totaliser counter    |
| 10         | Digital input 6 totaliser counter    |
| 11         | Digital input 7 totaliser counter    |
| 12         | Digital input 0 calculated flow rate |
| 13         | Digital input 1 calculated flow rate |
| 14         | Digital input 2 calculated flow rate |
| 15         | Digital input 3 calculated flow rate |
| 16         | Digital input 4 calculated flow rate |
| 17         | Digital input 5 calculated flow rate |
| 18         | Digital input 6 calculated flow rate |
| 19         | Digital input 7 calculated flow rate |
| 20         | Reserved                             |
| 21         | Digital input 0 logical value        |
| 22         | Digital input 1 logical value        |

| Identifier | Channel                       |
|------------|-------------------------------|
| 23         | Digital input 2 logical value |
| 24         | Digital input 3 logical value |
| 25         | Digital input 4 logical value |
| 26         | Digital input 5 logical value |
| 27         | Digital input 6 logical value |
| 28         | Digital input 7 logical value |
| 29         | MODBUS/EXPANSION 0 channel    |
| 30         | MODBUS/EXPANSION 1 channel    |
| 31         | MODBUS/EXPANSION 2 channel    |
| 32         | MODBUS/EXPANSION 3 channel    |
| 33         | MODBUS/EXPANSION 4 channel    |
| 34         | MODBUS/EXPANSION 5 channel    |
| 35         | MODBUS/EXPANSION 6 channel    |
| 36         | MODBUS/EXPANSION 7 channel    |
| 37         | MODBUS/EXPANSION 8 channel    |
| 38         | MODBUS/EXPANSION 9 channel    |
| 39         | MODBUS/EXPANSION 10 channel   |
| 40         | MODBUS/EXPANSION 11 channel   |
| 41         | MODBUS/EXPANSION 12 channel   |
| 42         | MODBUS/EXPANSION 13 channel   |
| 43         | MODBUS/EXPANSION 14 channel   |
| 44         | MODBUS/EXPANSION 15 channel   |
| 45         | MODBUS/EXPANSION 16 channel   |
| 46         | MODBUS/EXPANSION 17 channel   |
| 47         | MODBUS/EXPANSION 18 channel   |

| Identifier | Channel                     |
|------------|-----------------------------|
| 48         | MODBUS/EXPANSION 19 channel |
| 49         | MODBUS/EXPANSION 20 channel |
| 50         | MODBUS/EXPANSION 21 channel |
| 51         | MODBUS/EXPANSION 22 channel |
| 52         | MODBUS/EXPANSION 23 channel |
| 53         | MODBUS/EXPANSION 24 channel |
| 54         | MODBUS/EXPANSION 25 channel |
| 55         | MODBUS/EXPANSION 26 channel |
| 56         | MODBUS/EXPANSION 27 channel |
| 57         | MODBUS/EXPANSION 28 channel |
| 58         | MODBUS/EXPANSION 29 channel |
| 59         | MODBUS/EXPANSION 30 channel |
| 60         | MODBUS/EXPANSION 31 channel |
| 61         | Flag 0                      |
| 62         | Flag 1                      |
| 63         | Flag 2                      |
| 64         | Flag 3                      |
| 65         | Flag 4                      |
| 66         | Flag 5                      |
| 67         | Flag 6                      |
| 68         | Flag 7                      |
| 69         | Flag 8                      |
| 70         | Flag 9                      |
| 71         | Flag 10                     |
| 72         | Flag 11                     |

| Identifier | Channel                         |
|------------|---------------------------------|
| 73         | Flag 12                         |
| 74         | Flag 13                         |
| 75         | Flag 14                         |
| 76         | Flag 15                         |
| 77         | Digital output 0                |
| 78         | Digital output 1                |
| 79         | Digital output 2                |
| 80         | Digital output 3                |
| 81         | Digital output 4                |
| 82         | Digital output 5                |
| 83         | Digital output 6                |
| 84         | Digital output 7                |
| 93         | Math Channel 0                  |
| 94         | Math Channel 1                  |
| 95         | Math Channel 2                  |
| 96         | Math Channel 3                  |
| 97         | Digital input 8 logical value   |
| 98         | Digital input 9 logical value   |
| 99         | Digital input 10 logical value  |
| 100        | Digital input 11 logical value  |
| 101        | Digital input 12 logical value  |
| 102        | Digital input 13 logical value  |
| 103        | Digital input 14 logical value  |
| 104        | Digital input 15 logical value  |
| 105        | Moisture or temperature probe 0 |

| Identifier | Channel                         |
|------------|---------------------------------|
| 106        | Moisture or temperature probe 1 |
| 107        | Moisture or temperature probe 2 |
| 108        | Moisture or temperature probe 3 |
| 109        | Moisture or temperature probe 4 |
| 110        | Moisture or temperature probe 5 |
| 111        | Moisture or temperature probe 6 |
| 112        | Moisture or temperature probe 7 |
| 113        | Math Channel 4                  |
| 114        | Math Channel 5                  |
| 115        | Math Channel 6                  |
| 116        | Math Channel 7                  |
| 117        | MODBUS/EXPANSION 32 channel     |
| 118        | MODBUS/EXPANSION 33 channel     |
| 119        | MODBUS/EXPANSION 34 channel     |
| 120        | MODBUS/EXPANSION 35 channel     |
| 121        | MODBUS/EXPANSION 36 channel     |
| 122        | MODBUS/EXPANSION 37 channel     |
| 123        | MODBUS/EXPANSION 38 channel     |
| 124        | MODBUS/EXPANSION 39 channel     |
| 125        | MODBUS/EXPANSION 40 channel     |
| 126        | MODBUS/EXPANSION 41 channel     |
| 127        | MODBUS/EXPANSION 42 channel     |
| 128        | MODBUS/EXPANSION 43 channel     |
| 129        | MODBUS/EXPANSION 44 channel     |
| 130        | MODBUS/EXPANSION 45 channel     |

| Identifier | Channel                     |
|------------|-----------------------------|
| 131        | MODBUS/EXPANSION 46 channel |
| 132        | MODBUS/EXPANSION 47 channel |
| 133        | MODBUS/EXPANSION 48 channel |
| 134        | MODBUS/EXPANSION 49 channel |
| 135        | MODBUS/EXPANSION 50 channel |
| 136        | MODBUS/EXPANSION 51 channel |
| 137        | MODBUS/EXPANSION 52 channel |
| 138        | MODBUS/EXPANSION 53 channel |
| 139        | MODBUS/EXPANSION 54 channel |
| 140        | MODBUS/EXPANSION 55 channel |
| 141        | MODBUS/EXPANSION 56 channel |
| 142        | MODBUS/EXPANSION 57 channel |
| 143        | MODBUS/EXPANSION 58 channel |
| 144        | MODBUS/EXPANSION 59 channel |
| 145        | MODBUS/EXPANSION 60 channel |
| 146        | MODBUS/EXPANSION 61 channel |
| 147        | MODBUS/EXPANSION 62 channel |
| 148        | MODBUS/EXPANSION 63 channel |
| 149        | MODBUS/EXPANSION 64 channel |
| 150        | MODBUS/EXPANSION 65 channel |
| 151        | MODBUS/EXPANSION 66 channel |
| 152        | MODBUS/EXPANSION 67 channel |
| 153        | MODBUS/EXPANSION 68 channel |
| 154        | MODBUS/EXPANSION 69 channel |
| 155        | MODBUS/EXPANSION 70 channel |

| Identifier | Channel                     |
|------------|-----------------------------|
| 156        | MODBUS/EXPANSION 71 channel |
| 157        | MODBUS/EXPANSION 72 channel |
| 158        | MODBUS/EXPANSION 73 channel |
| 159        | MODBUS/EXPANSION 74 channel |
| 160        | MODBUS/EXPANSION 75 channel |
| 161        | MODBUS/EXPANSION 76 channel |
| 162        | MODBUS/EXPANSION 77 channel |
| 163        | MODBUS/EXPANSION 78 channel |
| 164        | MODBUS/EXPANSION 79 channel |
| 165        | MODBUS/EXPANSION 80 channel |
| 166        | MODBUS/EXPANSION 81 channel |
| 167        | MODBUS/EXPANSION 82 channel |
| 168        | MODBUS/EXPANSION 83 channel |
| 169        | MODBUS/EXPANSION 84 channel |
| 170        | MODBUS/EXPANSION 85 channel |
| 171        | MODBUS/EXPANSION 86 channel |
| 172        | MODBUS/EXPANSION 87 channel |
| 173        | MODBUS/EXPANSION 88 channel |
| 174        | MODBUS/EXPANSION 89 channel |
| 175        | MODBUS/EXPANSION 90 channel |
| 176        | MODBUS/EXPANSION 91 channel |
| 177        | MODBUS/EXPANSION 92 channel |
| 178        | MODBUS/EXPANSION 93 channel |
| 179        | MODBUS/EXPANSION 94 channel |
| 180        | MODBUS/EXPANSION 95 channel |

| Identifier | Channel                      |
|------------|------------------------------|
| 181        | MODBUS/EXPANSION 96 channel  |
| 182        | MODBUS/EXPANSION 97 channel  |
| 183        | MODBUS/EXPANSION 98 channel  |
| 184        | MODBUS/EXPANSION 99 channel  |
| 185        | MODBUS/EXPANSION 100 channel |
| 186        | MODBUS/EXPANSION 101 channel |
| 187        | MODBUS/EXPANSION 102 channel |
| 188        | MODBUS/EXPANSION 103 channel |
| 189        | MODBUS/EXPANSION 104 channel |
| 190        | MODBUS/EXPANSION 105 channel |
| 191        | MODBUS/EXPANSION 106 channel |
| 192        | MODBUS/EXPANSION 107 channel |
| 193        | MODBUS/EXPANSION 108 channel |
| 194        | MODBUS/EXPANSION 109 channel |
| 195        | MODBUS/EXPANSION 110 channel |
| 196        | MODBUS/EXPANSION 111 channel |
| 197        | MODBUS/EXPANSION 112 channel |
| 198        | MODBUS/EXPANSION 113 channel |
| 199        | MODBUS/EXPANSION 114 channel |
| 200        | MODBUS/EXPANSION 115 channel |
| 201        | MODBUS/EXPANSION 116 channel |
| 202        | MODBUS/EXPANSION 117 channel |
| 203        | MODBUS/EXPANSION 118 channel |
| 204        | MODBUS/EXPANSION 119 channel |
| 205        | MODBUS/EXPANSION 120 channel |

| Identifier | Channel                      |
|------------|------------------------------|
| 206        | MODBUS/EXPANSION 121 channel |
| 207        | MODBUS/EXPANSION 122 channel |
| 208        | MODBUS/EXPANSION 123 channel |
| 209        | MODBUS/EXPANSION 124 channel |
| 210        | MODBUS/EXPANSION 125 channel |
| 211        | MODBUS/EXPANSION 126 channel |
| 212        | MODBUS/EXPANSION 127 channel |
| 213        | Math Channel 8               |
| 214        | Math Channel 9               |
| 215        | Math Channel 10              |
| 216        | Math Channel 11              |
| 217        | Math Channel 12              |
| 218        | Math Channel 13              |
| 219        | Math Channel 14              |
| 220        | Math Channel 15              |
| 221        | Math Channel 16              |
| 222        | Math Channel 17              |
| 223        | Math Channel 18              |
| 224        | Math Channel 19              |
| 225        | Math Channel 20              |
| 226        | Math Channel 21              |
| 227        | Math Channel 22              |
| 228        | Math Channel 23              |
| 229        | Math Channel 24              |
| 230        | Math Channel 25              |

| Identifier | Channel         |
|------------|-----------------|
| 231        | Math Channel 26 |
| 232        | Math Channel 27 |
| 233        | Math Channel 28 |
| 234        | Math Channel 29 |
| 235        | Math Channel 30 |
| 236        | Math Channel 31 |